

StromPi 3 Firmware – Official Releases

- Firmware 1.0 – original Firmware Files
- Firmware 1.1 – Power Fail Warning
 - In the configuration terminal a new option has been included „warning-enable <option>“
 - If this option is enabled, a warning is sent through the serial interface, when the primary voltage source fails – this option is similar to the function „shutdown-enable“ where a warning is sent out to shutdown the Raspberry Pi